Crisp, tapered lines accentuate the bold stance of this sleek and modern sedan. Inside, available leather seating, MP3 sound system and mahogany colored accents create a comfortable yet stylish interior. The available Duratec V6 engine provides a head-turning combination of power and efficiency that will take you anywhere you want to go in style.

Mercury Milan is the perfect combination of sophistication and practicality. We invite you to explore this easy-to-use Quick Reference Guide to acquaint you with some of the features of your Mercury Milan.

1 Headlamps, Foglamps (if equipped), and Panel Dimmer Control
Turn the control one position to the right to turn on the parking lamps. instrument panel lamps, license plate lamps and tail lamps. Turn the control to the second position on the right to turn on the headlamps. Turn the control one position to the left to activate the autolamp feature (if equipped), which automatically turns the exterior lamps on and off, based on available daylight. The system also keeps the lights on for a short time after the ignition is turned off. Pull the control out to activate the fog lamps. The fog lamp indicator light will illuminate. The fog lamps will not operate when the control is turned off or when the high beams are on. Use the panel dimmer control to adjust the level of brightness on the instrument panel during parking lamp and headlamp operation. Move the control to the full upright position, past the detent, to turn on the interior lamps.

2 Traction Assist Light
(if equipped) This icon illuminates when the Traction Assist is active. If the light remains on, have the system serviced immediately by an authorized dealer.

3 Throttle Control / Transmission Light
This icon illuminates when a powertrain fault has been detected. Contact an authorized dealer as soon as possible.

4 Steering Wheel Controls
(if equipped) Your steering wheel controls allow you to set and adjust vehicle speed, as well as make adjustments in your audio and climate control systems.

The appearance of your vehicle's speed control switches may vary according to your option package.

To set the speed control, ensure that the vehicle speed is at least 30 mph. Press and release ON. Accelerate to the desired speed. Press and release SET (+). The speed control indicator light will illuminate in the cluster. Remove your foot from the accelerator. Once set, press and release SET (-) or (+) to decrease or increase the speed in small increments. Or, press and hold until you reach the desired speed. To disengage speed control but not erase the previous set speed, press the brake pedal or clutch pedal (if equipped). To disengage and erase the speed, press OFF.

Press – TEMP + to decrease / increase the cabin temperature.

Press – FAN + to decrease/increase fan speed.

Press – VOL + to decrease/increase audio volume.

Press MEDIA to select AM, FM1, FM2 or CD.

Press to access the previous / next preset radio station or CD track.

5 Check Engine Light
The Check Engine light illuminates briefly when the ignition is turned on. If the light remains on or flashes after the engine is started, the On Board Diagnostics System (OBD-II) has detected a malfunction. Drive in a moderate fashion and have your vehicle serviced immediately by an authorized dealer.

6 Airbag Readiness Light
The airbag readiness light illuminates briefly when the ignition is turned on. If this light remains on or continues to flash after the engine is started, have the system serviced immediately by your authorized dealer. A chime will also sound if a malfunction in the supplemental restraint system is detected.

7 Anti-lock Brake System (ABS) Warning Light
(if equipped) The ABS light illuminates briefly when the ignition is turned on. If the ABS light remains on or flashes after the engine is started, have the system serviced immediately by your authorized dealer. Normal braking (less ABS) will still be functional unless the brake warning light is also illuminated. **Note:** It is normal to feel a pedal pulsation or hear a slight noise when the ABS system is activated.

8 Tilt / Telescopic Steering Wheel Lever
Push the lever down to unlock the steering column. Move the steering wheel up or down and in or out to find the desired position. While holding the steering wheel in place, pull the lever up to lock the steering column.

9 Check Fuel Cap Light
This icon illuminates when the fuel cap may not be properly installed. If you continue to drive with this light illuminated the Check Engine indicator light may come on.

10 Brake System Warning Light
The brake system warning light illuminates briefly when the ignition is turned on. This light will remain on when the parking brake is applied and the ignition is on. If this light remains on after releasing the parking brake, this indicates a low brake fluid level or a brake system malfunction. Have the brake system inspected immediately by an authorized dealer.

11 In-Dash Clock
Press + to advance the time.

Press – to reverse the time.

Auxiliary Power Point
The auxiliary power point is located inside the center console utility compartment. **Note:** Do not use the power point over the capacity of 12VDC / 180W.

Power Outside Mirrors
Rotate the control clockwise to adjust the right mirror. Rotate the control counter-clockwise to adjust the left mirror. Move the control in the direction you wish to tilt the mirror. Return the control to the center position to lock the mirrors in place.

Integrated Keyhead / Keyfob Transmitter (IKT) and Remote Entry System Features
Your vehicle comes equipped with two specially programmed Integrated Keyhead Transmitters (IKTs). IKTs are both a programmed ignition key and a remote keyless entry transmitter. Handle the IKT carefully when starting the car to avoid accidentally pressing any of the remote entry buttons. Press once to unlock the driver's door. The interior lamps will illuminate. Press twice to unlock all the doors. Press once to lock all the doors and activate the perimeter alarm system (if equipped). Press twice to confirm all the doors and trunk are closed. The horn will chirp and the turn signal lamps will flash once if all the doors and the trunk are closed. Press to activate the panic alarm. The horn will sound and the turn lamps will flash. Press again or turn the ignition on to deactivate the panic alarm. Press to unlock the trunk.

Power Windows
Push down (to the first detent) and hold the switch to open. Pull up (to the first detent) and hold the switch to close. One touch down: This function allows the driver's window to open fully without holding the control down. Push the switch completely down to the second detent and release quickly. The window will then fully open. Momentarily press the switch to any position to stop the window operation.

Accessory Delay: With accessory delay, the window switches, audio system, and moonroof (if equipped) may be used for up to 10 minutes after the ignition switch is turned to the 1 (LOCK) (OFF) position or until any door is opened.

Moon Roof
(if equipped) The moon roof is equipped with a one-touch, express opening, closing, and venting feature. To open the moon roof, press and release the rear portion of the control. To close the moon roof, press and release the front portion of the control. To stop motion at any time during the one-touch operation, press the control a second time.

Additional Features

Auto Dimming Rear View Mirror (if equipped)
The rear view mirror will automatically darken when the mirror detects bright lights behind the vehicle to help minimize glare.

Rear Seat Release
Both rear seats can be folded down for additional cargo space. Pull the release handle located inside the trunk to fold down the seat.

SecuriLock™
The Securilock™ passive anti-theft system is an engine immobilization system. This system is designed to help prevent the engine from being started unless a coded Integrated Keyhead Transmitter (IKT) programmed to your vehicle is used. Using the wrong type of coded key may lead to a "no start" condition. The anti-theft indicator in the instrument cluster will flash to indicate the Securilock system is functioning as a theft deterrent when the ignition is turned off.

Autolock/Auto-unlock (if equipped)
Autolock automatically locks all vehicle doors when all the doors are closed, the ignition is in the RUN position, you shift into any gear that puts the vehicle into motion, and the vehicle is moving above 12 mph (20 km/h). Auto-unlock automatically unlocks all the doors when the vehicle has been traveling above 12 mph (20 km/h), comes to a complete stop, and the driver door is opened within 10 minutes of the ignition being turned off. **Note:** For instructions on disabling autolock, please refer to your Owner's Guide or see your authorized dealer.

BeltMinder®
The BeltMinder® is a supplemental warning system which intermittently chimes to alert the driver and passenger if their safety belts are not fastened. For further information, please refer to your Owner's Guide.

Message Center
The message center displays important vehicle information through a constant monitoring of vehicle systems. The message center displays features such as trip odometer, compass (if equipped), distance to empty, average fuel economy, and a language selector. The message center also provides vehicle system checks and will notify you of potential vehicle problems with a display of system warnings.

INFO: Press to scroll through the following displays: Odometer, Trip Odometer A or B, Distance to Empty, Average Fuel Economy, Average Speed, Compass (if equipped), and Trip Elapsed Time 1 or 2.

RESET: Press to select and reset functions shown in the Info (Information) and Setup Menu.

SETUP: Press to scroll through: System Check, Units (English/Metric), and Language (English, Spanish, or French).

For further information, please refer to your Owner's Guide.

Ford Motor Company

Customer Relationship Center
P.O. Box 6248
Dearborn, MI 48121
1-800-392-3673 (FORD)
(TDD for the hearing impaired: 1-800-232-5952)

This Quick Reference Guide is not intended to replace your Owner's Guide which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your occupants. Please read your entire Owner's Guide carefully as you begin learning about your new vehicle and refer to the appropriate sections when questions arise.

All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Mercury dealer is the best source for the most current information.

For detailed operating and safety information, please consult your Owner's Guide.

October 2005
Second Printing
Quick Reference Guide Mercury Milan
Litho in U.S.A.

6N7J-19G217-AA

Essential Information

Fuel Type and Tank Capacity
Your fuel tank can accommodate approximately 17.5 gallons (66.2 L) of gasoline. Your vehicle is designed to use unleaded gasoline with an (R+M)/2 octane rating of 87. Using gasoline with a lower octane rating may degrade performance.

Tire Pressure
Your vehicle's tire pressure specifications are found on the vehicle's Safety Compliance Certification Label located on the driver's door jamb. Check your tires for proper air pressure monthly; check the air pressure in your spare tire every six months. Always use an accurate tire pressure gauge. Check the tire pressure when tires are cold, after the vehicle has been parked for at least three hours or has been driven less than three miles. (As you drive, the temperature in the tire warms up, increasing the tire pressure.) Improperly inflated tires can affect vehicle handling and can fail suddenly, resulting in a possible loss of vehicle control. Refer to the Tires, Wheels and Loading chapter in the Owner's Guide for further information.

Fuses
If the vehicle's electrical components are not operating, a fuse may have blown. The fuse panel is located below the instrument panel on the driver's side; remove the cover to view the fuses. Additional fuses are located in the power distribution box in the engine compartment. For more information regarding changing fuses, refer to the Roadside Emergencies chapter of your Owner's Guide.

Fuel Pump Shut-off Switch
The fuel pump shut-off switch stops the electric fuel pump from sending fuel to your engine when your vehicle has sustained a substantial jolt. The switch is located in the passenger's footwell, by the kick panel. For more information regarding the fuel pump shut-off switch, refer to the Roadside Emergencies chapter of your Owner's Guide.

Location of Spare Tire and Tools
The spare tire and jack are located in the trunk below the carpeted floor panel. The necessary tools are contained in the tool bag. For complete details on how to change your tire, refer to the Roadside Emergencies chapter in your Owner's Guide.

Roadside Assistance
During your Mercury Milan's 3-year/36,000 mile limited warranty period, the assurance and support of a 24-hour emergency roadside assistance program is included. Roadside assistance includes such services as fuel delivery, tire changes, jump starts, help when you are locked out of your vehicle, and towing. To receive roadside assistance in the United States, call **(800) 241-3673.** In Canada, call **(800) 665-2006.**

Climate Control

Electronic Automatic Temperature Control System (EATC) (if equipped)

1 **AUTO**
Press to activate automatic temperature control. The system will automatically determine fan speed, airflow location, A/C (on or off) and outside or recirculated air, to heat or cool the vehicle to reach the desired temperature. Press again to deactivate.

2 **Manual Override Controls**
Allows you to manually determine where airflow is directed. To return to fully automatic control, press AUTO.

– Distributes air through the windshield defroster ducts, demister outlets and the front and rear seat floor ducts.

– Distributes air through the front and rear seat floor ducts.

– Distributes air through the instrument panel registers and the front and rear seat floor ducts.

– Distributes air through the instrument panel registers.

3 **EXT**
Press to display the outside air temperature.

4 **Defrost**
Distributes outside air through the windshield defroster and demister vents. Can be used to clear thin ice or fog from the windshield.

5 **Rear Window Defroster**
Press to clear the rear window of thin ice and fog. Press again to deactivate. The defroster will turn off automatically after 10 minutes. If your vehicle is equipped with both a rear defroster and heated mirrors, the same button will activate both.

6 **Recirculation Control**
Press to recirculate cabin air. Recirculated air may reduce the amount of time needed to cool down the interior of the vehicle and may also help reduce undesirable odors from reaching the interior of the vehicle. To reduce window fogging, do not drive with engaged and A/C off.

Driver/Passenger Heated Seats (if equipped)
Press once for high heat (two lights), twice for low heat (one light) and a third time to deactivate (no lights).

For Maximum Cooling Performance
Press , **A/C**, and set the temperature to 60 F (16 C) and the highest blower setting.

CENTER CONSOLE

Audio System

Premium/Audiophile AM/FM Stereo In-Dash Six CD/MP3 Sound System (if equipped)

A **ON/OFF/Volume:** Press to turn ON/OFF. Turn to increase/decrease volume. If the volume is set above a certain level and the ignition is turned off, the volume will come back on at a "nominal" listening level when the ignition switch is turned back on.

B **MUTE:** Press to mute the playing media. Press again to return to the playing media.

C **SHUFFLE:** Press to play all CD/MP3 tracks on the current disc in random order.

D **SEEK:** Press to access the previous (◄) or next (►) strong radio station or CD track.

E **TEXT/SCAN:** Press and hold for a brief sampling of radio stations or CD tracks. Press again to stop. In CD/MP3 mode, press TEXT to display track title, artist name, disc title and file name (if available).

F **Memory Presets:** To set a station: Select frequency band AM/FM1/FM2; tune to a station, press and hold a preset button until sound returns. You can store up to 18 stations, six in AM, six in FM1 and six in FM2.

G **Load:** Press to load a CD. Press LOAD and a memory preset to load to a specific slot. Press and hold to autoload up to six CDs.

H **MENU:** Press to toggle through:

Autoset: Allows you to set the strongest local radio stations without losing your original stored stations for AM/FM1/FM2. Use ▲/▼ to turn on/off. When the six strongest stations are filled, the station stored in preset 1 will begin playing. If there are less than six strong stations, the system will store the last one in the remaining presets.

Occupancy mode: (Available on Audiophile radios only) Use ▲/▼ to select and optimize sound for ALL SEATS, DRIVERS SEAT or REAR SEATS.

Speed sensitive volume: Radio volume automatically changes slightly with vehicle speed to compensate for road and wind noise. Recommended level is 1-3. Level 0 (SPEED OFF) turns the feature off and level 7 is the maximum setting.

RBDS (Radio Broadcast Data System): In FM mode, this feature allows you to search categories of music or announcements. For further information, please refer to your Owner's Guide.

Compression: Brings soft and loud CD passages together for a more consistent listening level when in CD mode. Press MENU until compression status is displayed. Press ▲/▼ to turn the feature on/off.

Track/Folder Mode: Available in CD/MP3 mode only.

Press ▲/▼ to toggle between Track and Folder mode.

In track mode, press ◄ SEEK ► to scroll through all tracks on the disc.

In folder mode, press ◄ SEEK ► to scroll through all tracks within the selected folder.

I **Tune/Disc Selector:** Press and release to manually advance up/down the radio frequency or to access the next/previous disc. Also used to make selections within the MENU function.

2006 MERCURY MILAN QUICK REFERENCE GUIDE

MERCURY NEW DOORS OPENED